







Photosensor prevents sludge inflow, helps discharge only supernatant liquid. Ideal for use under unstable water levels.



Features

- The sludge surface monitoring device prevents unexpected inflow of sludge and helps the pump solely discharge supernatant liquid.
- A float makes the pump particularly useful for the application where the water level fluctuates widely.
- An incorporated control circuit automatically stops operation upon receiving warning signals from the photosensor which would detect a water level drop to near the sludge interface layer.
- The sensor surfaces are automatically washed with pressurized water to be kept clean for perfect monitoring.

Applications

- · Discharging supernatant liquid in SBR
- Discharging supernatant liquid at a facility where such process is required



Surumi FHP-series displays high effect for the discharge of supernatant liquid in SBR.

Major Components & Specifications


Discharge Bore mm			40	50	80	
Pumping Fluid	Type of Fluid		Treated Water			
	Fluid Tem	perature	0 to 40℃			
	Structure	Impeller	Channel			
		Shaft Seal	Double Mechanical Seal			
		Bearing	Double-shielded Ball Bearing			
Pump	Materials	Impeller	Gray Cast Iron			
		Casing	Gray Cast Iron			
		Shaft seal	Silicon Carbide			
		Float	FRP			
Motor	Type, Pole		Dry Type Submersible Induction Motor, 2-pole			
	Insulation		E F (1.5kW only)			
	Phase		Single-phase Three-phase (suffix "T")			
	Starting Method		Capacitor Start (Single-phase only) Direct on Line			
	Protection Device (built-in)		Circle Thermal Protector			
	Lubricant		Turbine Oil (ISO VG32)			
	Materials	Frame	Gray Cast Iron			
		Shaft	420 Stainless Steel			
		Cable	PVC			
Discharge Connection			Hose Coupling			

Model Selection 50/60Hz


Discharge Bore mm	Model	Motor Output kW	Phase	Speed (S.S.) min ⁻¹	Starting Method	Dry Weight* kg	Cable Length m
40	FHP4-3	0.25	Single	3000/3600	Capacitor Start	29	6
40	FHP3-3T	0.25	Three	3000/3600	D.O.L.	27	6
50	FHP3-4	0.4	Single	3000/3600	Capacitor Start	29	6
50	FHP2-4T	0.4	Three	3000/3600	D.O.L.	27	6
50	FHP4-8T	0.75	Three	3000/3600	D.O.L.	28	6
80	FHP3-15T	1.5	Three	3000/3600	D.O.L.	60	6


^{*}Weights excluding cable

Dimensions Unit:mm



Performance Curves






Standard Accessories

- Hose Coupling
- · Anti-sludge Sensor Cable 6m
- Lifting Chain 3m* (with Shackles)
 *5m for 1.5kW
- 311 101 1.3844

Optional Accessories

- Guide Rail Fitting Set
- Guide Support
- Guide HookGuide Pipe Fixing Plate
- Stopper



01 | TSURUMI PUMP | 02

Structural Features


Float

The float sustains a submersible pump by buoyancy at an appropriate position. Made of fiber reinforced plastic (FRP), the float is filled with polystyrene foam which prevents the loss of buoyancy in case the float is broken.

2 Intake Check Ball


A check ball incorporated in the intake closes the suction mouth by buoyancy when the pump stops operating thus preventing the inflow of floating sludge. During operation, the ball is sucked in by the pump's suction power to take in supernatant liquid.





3 Pumping Section

Each component, such as dual inside mechanical seal, motor protector, and anti-wicking cable entry, represents Tsurumi's outstanding expertise.



Anti-sludge Sensor

When the amount of light transmitted from an emitter via glass fibers is reduced by a certain density of sludge existing in the liquid, the sensor identifies the light amount and sends corresponding signals to the control panel to stop or operate the pump not to suck up sludge.





Sensor Cleaner

The sensor cleaner spouts a jet of clean water from its nozzle to wash the light emitter and receiver at fixed intervals. The pressurized water can be treated water coming from a submersible pump installed in the spray pump tank.

Recommendation;

- The washing shall be performed for 5 minutes every 1.5 hours during the aeration process.
- The amount of washing water shall be regulated with a valve over a range of 10 to 20 L/min and the pressure, 0.5 to 1 kg/cm².



We reserve the right to change the specifications and designs without prior notice. The OO series and model OO are indicated with our series/model codes in this catalog.

TSURUMI MANUFACTURING CO., LTD.

www.tsurumi-global.com





Web

Social Media

Your Dealer